



How To Make ME-850 Landisk Work Under Windows Vista

- Samba Server Support in Vista

1. Open "Run" window




2. Type "secpol.msc" and click "OK"




3. Click “Continue” when Vista ask for confirmation


4. When “Local Security Policy” window come up, click (high-light) “Local Policy → Security Options” on the left panel



5. Click “Network Security: LAN Manager authentication level” on the right panel



6. New window pop up, change the default value “NTVLM2 responses only” to “LM and NTLM – use NTLMV2 session security if negotiated”



7. Click “OK”, restart both LANDISK and the Vista system.