

## OTG Host/Device Mode Compatibility Supporting List

### Host Mode USB device support List

USB DSC/DV	USB PenDrive/MP3
AipTek PocketDV 3500	Ali M5634 USB2.0 Pendrive
AipTek PocketCam 4000	Ali M5633 USB2.0 Pendrive
BenQ DC140	Ali M5651 USB2.0 Pendrive
BenQ DC2300	ADMEGA 64MB
BenQ DC2310	Apacer NV400
BenQ DC2410	Apacer HANDY 2.0
BenQ DC5330	Apacer Audio STENO NV400(USB 2.0)
BenQ DCC40	CREATIVE MP3 LX100
CASIO EX-Z40	Diamond 64MB
CANON 300D	Easy disk 32MB
CANON A60	Fujifilm 256MB
CANON A75	LG 2.00311E+11 128MB
CANON A80	Leadtek USB disk 2.0
CANON A300	MicroFlashDisk MFT032M 32MB
CANON G5	MSI MEGA STICK 1 USB1.1
CANON S50	New man 128MB
CANON S60	NAND 128MB
CANON PowerShotA60	Netac U-Disk USB1.1
CANON PowerShotS50	Inter-Stick (PQI) USB2.0 Pendrive
CANON PowerShotA70	Onlydisk H032-32MB
CANON S1IS	Oti002168 160MB
CANON IXUS I	Oti006828 64MB
CANON IXUS 1IS	PATRIOT(愛國者) USB1.1 U-Disk
CANON IXUS 400	Pen Drive mp3 128MB
CANON IXUS 500	Phison PS2044 Pendrive
EPSON L-40	Sony USB1.1 Pen drive
FUJIFILM 3800	SAMSUNG 128MB
FUJIFILM FinePix2650	SanDisk Cruzer mini (GL813)
FUJIFILM S5000	SamSung YP-55
FUJIFILM S7000	TCL USB1.1 U-Disk
FUJIFILM A210	Regotech 128MB Multi-player
FUJIFILM A310	USB Adapter 32MB
FUJIFILM A340	U-BEST
FUJIFILM Q1	紫光 32MB
FUJIFILM F410	天若 M818A 64MB
FUJIFILM F420	<b>USB Card Reader</b>
FUJIFILM F610	Ali M5635 Card Reader
FUJIFILM F700	CR-T2-UCS USB1.1
FUJIFILM S20 PRO	SanDisk SDDR-97 USB2.0
KODAK 7630	SONY MSAC-US30 USB2.0
KODAK DX6490	Cypress ISD 300A1 USB2.0
KODAK EasyShare DX340 USB2.0	Genesys GL816 Card Reader
KODAK DX6490	CR-T3-U26
KODAK LS6-33	SMSC USB97C210-NE
KODAK LS743	NEODIO ND3260-LA
Kyocera Finecam S3L	<b>Exteranl USB Mass Starge device</b>

Kyocera Finecam S5R	Ali M5621 USB2.0 to IDE device
Kyocera Finecam SL300R	Ali M5642 USB2.0 to IDE device
Konica KD-310Z	Cypress AT2 series USB2.0 to IDE device
Konica KD-400Z	Genesys GL811-E USB2.0 to IDE device
Konica KD-410Z	ISD 300A1 USB2.0 to IDE device
Konica KD-500Z	Myson CS8813 USB2.0 to IDE device
Mustek mini DV	NEC0720130GC USB2.0 to IDE device
Mustek DV5500	
MINOLTA DiIMAGE Xt USB1.1	
MINOLTA DiIMAGE A1	
MINOLTA DiIMAGE A2	2.Device Mode HDD support list
MINOLTA DiIMAGE 5	1" HDD
MINOLTA DiIMAGE 7Hi	GS MagicStor 1" ATA interface 2.2GB
MINOLTA DiIMAGE F200	Seagate 1"ATA interface 5GB
MINOLTA DiIMAGE F300	CORNICE 1" ATA interface 2GB
MINOLTA DiIMAGE Xi	1.8" HDD
MINOLTA DiIMAGE X20	HITACHI ATA-6、 4200RPM 20GB
MINOLTA DiIMAGE Z1	
MINOLTA DiIMAGE Z2	
NIKON 3200	
NIKON 4100	
NIKON 5700	
NIKON D70	2.5" HDD
NIKON D100	IBM Travelstar,ATA-5、 4200RPM,10GB
NIKON CoolPix 4100	IBM Travelstar,ATA-4、 4200RPM, 6GB
NIKON CoolPix 4200	TOSHIBA, ATA-5、 4200RPM, 40GB
NIKON CoolPix 5000	Seagate, ATA-6、 5400RPM, 20GB
NIKON CoolPix 3100	HITACHI Travelstar, ATA-5、 5400RPM, 40GB
NIKON CoolPix 4300	HITACHI Travelstar, ATA-5、 5400RPM, 30GB
NIKON CoolPix 4500	HITACHI Travelstar, ATA-5、 5400RPM, 20GB
NIKON CoolPix 5700	Fujitsu, ATA-6、 4200RPM, 30GB
NIKON CoolPix 8700	Fujitsu, ATA-6、 4200RPM, 40GB
NIKON CoolPix SQ	Fujiysu,ATA-6、 4200RPM, 15GB
NIKON CoolPix D70	IBM Travelstar, ATA5、 4200RPM,20GB
OLYMPUS C-50Z	
OLYMPUS C-2	
OLYMPUS C-2Z	3.5" HDD
OLYMPUS C-150Z	Seagate Barracuda ATA/V Ultra ATA100、 7200RPM 20GB
OLYMPUS C-160Z	Seagate Barracuda ATA/V Ultra ATA100、 7200RPM 40GB
OLYMPUS C-310Z	Seagate Barracuda ATA/V Ultra ATA100、 7200RPM 120GB
OLYMPUS C-360Z	Seagate Barracuda 7200.7 Ultra ATA100、 7200RPM 80GB
OLYMPUS C-460Z	Seagate Barracuda 7200.7 Ultra ATA100、 7200RPM 120GB
OLYMPUS C-730	Western Digital WD200 Ultra ATA100、 7200RPM 20GB
OLYMPUS C-730 WZ	Western Digital WD600 Ultra ATA100、 7200RPM 60GB
OLYMPUS C-740 WZ	Western Digital WD800 Ultra ATA100、 7200RPM 80GB
OLYMPUS C-750 WZ	Western Digital WD2000 Ultra ATA100、 7200RPM 200GB
OLYMPUS C-760 WZ	Maxtor DiamondMax Plus 8 Ultra ATA 133、 7200RPM 20GB
OLYMPUS C-765 WZ	Maxtor DiamondMax Plus 9 Ultra ATA 133、 7200RPM 80GB

OLYMPUS C-770WZ	Maxtor DiamondMax 16 Ultra ATA 133, 5400RPM 160GB
OLYMPUS C-4000Z	HITACHI Deskstar TM Ultra ATA 100, 7200RPM 185GB
OLYMPUS C-5000Z	
OLYMPUS C-5050Z	
OLYMPUS C-5060Z	
OLYMPUS C-5060WZ	
OLYMPUS C-8080WZ	
OLYMPUS MJU-300	
OLYMPUS MJU-400	
OLYMPUS MJU-410	
OLYMPUS U100	
OLYMPUS U200	
OLYMPUS U300	
OLYMPUS Digital E-1	
OLYMPUS X-1	
OLYMPUS X-2	
PANASONIC DMC-FX1	
PANASONIC Z1	
PANASONIC NV65	
SamSung Digimax V3 USB1.1	
SamSung Digimax 202	
Samsung Digimax V5	
Samsung Digimax XT	
Samsung Minolta	
SONY F77	
SONY F828	
SONY F717	
SONY P1	
SONY P8	
SONY P9	
SONY P12	
SONY P32	
SONY P43	
SONY P52	
SONY P72	
SONY P73	
SONY P77 USB1.1	
SONY P92	
SONY P93	
SONY P100	
SONY T1	
SONY T11	
SONY U20	
SONY U30	
SONY U50	
SONY U60	
SONY V1	
SONY W1	

<b>SONY DCR-TRV38E</b>	
<b>SONY F828</b>	
<b>Sony CyberShotUSB1.1</b>	
<b>Sanyo AZ1</b>	
<b>Sanyo AZ3</b>	
<b>UMAX AstraPix 610</b>	
<b>Canon power shot S40/S45</b>	
<b>Canon D60</b>	
<b>Canon 10D</b>	
<b>RICON G4 Wide</b>	
<b>PANTAX S-40</b>	
<b>PANASONIC DV PV-GS50S</b>	
<b>DIGILIFE DGL660</b>	
<b>SONY DV DCR-TRV22</b>	
<b>ORIT EVC3240</b>	
<b>FUJIFILM FinePix F410</b>	
<b>KODAK EasyShare DX340 USB2.0</b>	
<b>mustek dv4000</b>	